


RD-KL46Z-MRE

Magnetic rotary encoder reference design kit

Rev. 1.0 — 2 June 2016

User guide

1 RD-KL46Z-MRE



2 Important notice

NXP provides the enclosed product(s) under the following conditions: This reference design is intended for use of ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY. It is provided as a sample IC pre-soldered to a printed circuit board to make it easier to access inputs, outputs, and supply terminals. This reference design may be used with any development system or other source of I/O signals by simply connecting it to the host MCU or computer board via off-the-shelf cables. Final device in an application is heavily dependent on proper printed circuit board layout and heat sinking design as well as attention to supply filtering, transient suppression, and I/O signal quality.

The goods provided may not be complete in terms of required design, marketing, and or manufacturing related protective considerations, including product safety measures typically found in the end product incorporating the goods. Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge. In order to minimize risks associated with the customers applications, adequate design and operating safeguards must be provided by the customer to minimize inherent or procedural hazards. For any safety concerns, contact NXP sales and technical support services.

As a prototype, this product does not fall within the scope of the European Union directive on electromagnetic compatibility and therefore may not meet the technical requirements of the directive. Please be aware, the products received may not be regulatory compliant or agency certified (FCC, UL, CE, etc.).

Note: Optional text for boards and user guide have not completed FCC testing.

Should this reference design not meet the specifications indicated in the kit, it may be returned within 30 days from the date of delivery and will be replaced by a new kit.

NXP reserves the right to make changes without further notice to any products herein. NXP makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typical", must be validated for each customer application by customer's technical experts.

NXP does not convey any license under its patent rights nor the rights of others. NXP products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the NXP product could create a situation where personal injury or death may occur.

Should the Buyer purchase or use NXP products for any such unintended or unauthorized application, the Buyer shall indemnify and hold NXP and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges NXP was negligent regarding the design or manufacture of the part. NXP and the NXP logo are trademarks of NXP B.V. All other product or service names are the property of their respective owners. © 2016 NXP B.V.

3 Getting started

3.1 Kit contents/packing list

The RD-KL46Z-MRE contents include:

- Assembled and tested evaluation module:
 - RD-KL46Z-MRE evaluation board
 - BRKT-STBC-AGM01 breakout board
 - FRDM-KL46Z development board
- USB cable
- Warranty card

3.2 Jump start

All product development boards are accompanied by a Jump Start bundle available on the board's tool summary page. Jump Start bundles offer current versions of the resources related to the board. The bundles provide everything needed to begin using the board in a design environment. To access the Jump Start bundle:

1. Go to nxp.com/RD-KL46Z-MRE.
2. Review your Tools Summary Page.
3. Locate and click:



4. Download the documents, software, and other information.

4 Hardware description

The RD-KL-46Z-MRE is a reference design kit that supports system designs based on NXP's FXOS8700CQ, a 6-axis sensor with an integrated linear accelerometer and a magnetometer.

4.1 Kit overview

The kit contains an RD-KL46Z-MRE evaluation board, a BRKT-STBC-AGM01 breakout board, an FRDM-KL46Z development board, and a USB cable with a type-A plug and a Mini-B plug. See [Figure 1](#).

The top board of the RD-KL46Z-MRE demonstrates the magnetic rotary encoder. It is composed of an LCD screen, a knob connected to a diametrically magnetized magnet, and several interfaces to communicate with an external IC.

The middle board, the BRKT-STBC-AGM01 breakout board, contains two NXP sensors:

- FXOS8700, a 6-axis accelerometer and magnetometer
- FXAS21002, a 3-axis gyroscope

The FXOS8700 is used to measure the magnetic field of a magnet. The air gap is not adjustable on the demo board, because of the mechanical parts. However, for a final application (end customer product), the user must make sure the magnetic

field measured by the sensor is within the range of 200 μ T and 600 μ T to maintain an accurate calibration algorithm.

The bottom board, the FRDM-KL46Z development board, is a simple yet sophisticated design featuring a Kinetis L series microcontroller, built on the ARM[®] Cortex[™]-M0+ core.




Figure 1. RD-KL46Z-MRE evaluation kit

4.2 Block diagram





Figure 2. RD-KL46Z-MRE Block Diagram

4.3 Board description

The RD-KL46Z-MRE is a circuit board allowing the user to exercise all the functions of the NXP FXOS8700 magnetometer.



4.4 Freedom board configuration

The RD-KL46Z-MRE is compatible with the FRDM-KL46Z Freedom evaluation board.

When used in this configuration, the RD-KL46Z-MRE mounts to the surface of the Freedom board by means of the onboard Arduino™ connectors (connectors J1, J2, J9 and J10).

5 Setting up the hardware

5.1 Prepare the drivers

- Plug one end of a USB cable into the OpenSDA port on the FRDM-KL46Z board. Plug the other end of the cable into a USB port on the computer.

After connecting the FRDM-KL46Z board to the computer, Microsoft® Windows® automatically adds the following two devices to the computer's device manager.

- A portable device to flash the MCU
- A serial port to communicate with the board

After the driver installation, the serial port number beginning with COM appears. Write this number down for use with the Graphical User Interface (GUI) later.

5.2 Install the GUI

Download the GUI from nxp.com/RD-KL46Z-MRE. Install the NXP Magnetic Rotary Encoder GUI.

5.3 Flash the MCU

Execute the GUI that was just installed. See [Figure 4](#).

1. Click on the **Settings** button.
2. Click on the FRDM-KL46Z picture, and then click the **Flash** button.
3. In the **Browse For Folder** window, click on the drive labeled **FRDM-KL46Z**, and then click **OK**.
4. Wait for a moment, about 20 to 30 seconds.
5. When the board is flashed and ready, and a confirmation dialog box appears, click **OK**. See [Figure 5](#).




Figure 4. Flash the MCU




Figure 5. Program upload! window

5.4 Establish communication

The NXP Magnetic Rotary Encoder evaluation board is now ready to be used. Some information is displayed in the embedded LCD screen. Additional parameters and options are available by using the NXP Magnetic Rotary Encoder software. If the MRE software is not running, start the program and complete the following steps.

1. Confirm that the USB cable is still connected to the computer and the evaluation board.
2. Click the **Angle sensor** button. See [Figure 6](#).
3. Click the **Port** drop-down menu and select the appropriate serial port number. This number was acquired in [Section 5.1](#).
4. Click the **Connect** button.




Figure 6. Establishing communication

The status indicator in the Communication panel should change to **Connected**. See [Figure 7](#).




Figure 7. Connected to a computer and communicating

If the board is connected to a computer, but does not communicate with the computer, the status indicator changes to **Failed**. See [Figure 8](#).




Figure 8. The board is connected to a computer, but not communicating

If the board was communicating with a computer, but the USB cable was disconnected an alert icon appears next to the **Connected** status indicator. The alert icon also appears if an attempt was made to connect to an incorrect port. See [Figure 9](#).




Figure 9. Port com is connected, but there is no response from the rotary board

Clicking on the **Disconnect** button changes the status indicator changes to **Disconnected**. See [Figure 10](#).




Figure 10. The board is not connected to a computer

5.5 Calibrate the sensor

The first time the board is powered on, the sensor launches a self-calibration phase to correct measured magnetic fields and increase the knob angle position accuracy.

- A blinking red LED indicates that the board is not calibrated.
- A blinking blue LED indicates that the board is collecting the data from the sensor for self-calibration.


To calibrate the sensor, rotate the knob 360 degrees in either direction. This initiates data collection.

When the data collection is finished, the blue LED stops blinking and the knob can be released. When the calibration is computed, the blue LED is turned off. When the calibration is fully functional, the green LED blinks.

Once the board is calibrated, it is necessary to set the zero reference point.

1. Align the cursor knob marker to the zero degree indicator in the protractor.

- Press the zero button (SW2) on the board and release, or click on the **Zero** button in the GUI. See [Figure 11](#).



6 Using the software

Now all functionalities provided by the NXP Magnetic Rotary Encoder GUI are available. Check the figures below and start experimenting.

6.1 Angle sensor window

Clicking on the **Angle sensor** button brings up the main window, see [Figure 12](#). The information in this window is described below.




Figure 12. Angle sensor window

- **Knob angular position.** The angular position of the knob in degrees is displayed in the upper left portion of the window.
- **Angular speed.** The bottom right area of the window displays the angular speed. This is the speed, in revolutions per minute, in which the knob is rotated.
- **Calibration panel.** When the **Allow self-calibration** check box is checked, the RD-KL46Z-MRE recalibrates when the current calibration is determined to be obsolete. Clicking on the **Start new calibration** button causes the board to calibrate. The calibration status is displayed in this panel. The various status modes are described later.
- **User command panel**
 - Sets the zero angle reference
 - Sets the accuracy vs. speed ratio
 - Changes the direction of the rotation
- **Communication panel**
 - Selects the serial port number
 - Connects or disconnects the board
 - Displays the communication status

6.2 Magnetics window

Clicking the **Magnetics** button brings up the **Magnetics** window. There are three tabs available in this window: **Time view**, **XY view**, and **Angle error view**. Each of these views is described in the following sections.

6.2.1 Time view




Figure 13. Time view

- **Magnetics panel.** The magnetic field values in each of the three axes (X,Y,Z) are displayed in real time.
- **Clear button.** Clicking this button clears the current graph and begins a new graphing session.
- **Zoom buttons.** These buttons control the range displayed in the graph.
 - Clicking the + (plus) button increases the amount of data shown per second. The graph scrolling speed increases.
 - Clicking the – (minus) button decreases the amount of data shown per second. The graph scrolling speed decreases.
- **Save button.** Clicking this button saves the current paused graph to a .csv file.
- **Pause button.** Clicking this button stops the current graph, making it available to save. Clicking it again resumes the graphing session.
- **Calibrated data check box.** When **Calibrated** data is set, the calibrated data is shown. When the check box is clear, the graph displays uncalibrated data.

6.2.2 XY view




Figure 14. X/Y view

- **Computed phase panel.** Raw and calibrated angle values, in degrees, are displayed.
- **Clear button.** Clicking this button clears the current graph and begins a new graphing session.
- **Zoom buttons.** These buttons control the weight of each point displayed in the graph.
 - Clicking the + (plus) button increases the weight (pixel size) of each data point.
 - Clicking the – (minus) button decreases the weight (pixel size) of each data point.
- **Scale button.** Clicking this button rescales the chart to best fit the window.
- **Save button.** Clicking this button saves the current paused graph to a .csv file.
- **Raw data and Calibrated data check boxes.** When there is a check in each check box, the corresponding data is displayed.

6.2.3 Angle error view




Figure 15. Angle error view

- **Error display window.** The difference in degrees between the raw angle and the calibrated angle. The value displayed is the angle correction added to the raw value.
- **Clear button.** Clicking this button clears the current graph and begins a new graphing session.
- **Zoom buttons.** These buttons control the range displayed in the graph.
 - Clicking the + (plus) button increases the amount of data shown per second. The graph scrolling speed increases.
 - Clicking the – (minus) button decreases the amount of data shown per second. The graph scrolling speed decreases.
- **Pause button.** Clicking this button stops the current graph, making it available to save. Clicking it again resumes the graphing session.

7 Understanding calibration state and self-calibration

The various calibration states available are described in this section. See [Figure 16](#). Understanding these states helps make the algorithm easier to comprehend.




Figure 16. Calibration

The sensor can be in four different states:

- Uncalibrated
- Calibrated
- Warning
- Obsolete


When the RD-KL46Z-MRE is powered up for the first time, the calibration state is Uncalibrated. The self-calibration option is initially enabled; therefore, the board begins a new calibration cycle. Completion of this cycle requires turning the knob one complete rotation in either direction.

The self-calibration mode can be disabled by clearing the **Allow calibration** check box in the **Angle sensor** tab.

If an unusual magnetic disruption is detected, the calibration state changes to Warning and the LEDs change color to orange. When the disruption ends, the calibration state changes to Calibrated. If the disruption continues for a few seconds, the calibration state changes to Obsolete. During the Obsolete state, the sensor continues to use the previous calibration profile, even though it is considered by the system to be obsolete. If the Self-calibration mode is enabled, the sensor continues to attempt to return to the Calibrated state.

8 Understanding data output

The GUI offers several data visualizations and configurations. The next diagram summarizes the data processing chain. This diagram is published for guidance purposes and is not exhaustive.



9 Advanced operations

9.1 Customizing the RD-KL46Z-MRE

The RD-KL46Z-MRE reference design offers different add-ins to improve and test your design:

- An external power supply to make the kit autonomous
- A UART interface to connect to other modules, such as a Bluetooth® module
- A filtered PWM output mode to use a simple analog-to-digital converter with an external MCU as a way of providing the knob angle
- A slave SPI communication to configure and acquire data with an external MCU




Figure 18. Customized RD-KL46Z-MRE board with battery and Bluetooth® module

9.2 PWM output

The analog output provides the calibrated angle value. The output value is between 0 V and 3.3 V, the latter being the board power supply. The output voltage is proportional to the knob angle: the full scale is 0 V to 3.3 V for 0° to 360°, therefore the resolution is 0.00916 V/°.




Figure 19. Ratio of output voltage to knob angle

To use this functionality, plug the ANGLE pin to an MCU analog-to-digital input (ADC). Remember to connect the grounds together (GND pin to MCU GND).




Figure 20. How to connect MCU to the sensor PWM output

9.3 SPI bus

It is possible to control, configure and read data from the magnetic angle sensor by using the SPI bus. Note that the bus is 1.8 V to 5.5 V compliant, and that its maximum speed is 12 MHz. Remember to connect the external MCU supply voltage to the VCC_M and GND pins.




Figure 21. How to connect the sensor to SPI bus

The SPI bus has to be configured in Mode 0 (polarity and phase to low level) for 8-bit transfer. To read or write to a register, you must reset the chip select pin (SCS-/CS).




Figure 22. Timing diagram

9.4 Register descriptions

Table 1. Register address map

Name	Type	Register address	Auto-increment address	Reset	Comment
STATUS	R	0x00	0x01	0x03	Real Time calibration status
CTRL_REG	W	0x20	0x02	0x00	Configuration register
WHO_AM_I	R	0x0D	0x03	0x0A	Device ID
ANGLE_MSB	R	0x01	0x04	0x00	[7:0] are the 8 MSBs of the 16-bit real time angle value
ANGLE_LSB	R	0x02	0x05	0x00	[7:0] are the 8 LSBs of the 16-bit real time angle value
SPEED_MSB	R	0x03	0x06	0x00	[7:0] are the 8 MSBs of the 16-bit real time speed value
SPEED_LSB	R	0x04	0x00	0x00	[7:0] are the 8 LSBs of the 16-bit real time speed value

9.4.1 STATUS - Status register (address 00h)

Table 2. STATUS - Status register (address 00h) bit allocation

Bit	7	6	5	4	3	2	1	0
Symbol	reserved		mag_range	cal_prog	cal_state [1:0]		rev_rot	self_cal
Reset	—	—	0	0	0b00		1	1
Access	R	R	R	R	R	R	R	R

Table 3. STATUS - Status register (address 00h) field descriptions

Bit	Symbol	Description
5	mag_range	Set to 1 if the magnetic field read by the sensor is adequate for the calibration and the correction 0: Magnetic field is not in the angle sensor range (default) 1: Magnetic field is in the angle sensor range
4	cal_prog	Set when a new calibration phase is in progress 0: The calibration phase is stopped (default) 1: A calibration phase is running
3 to 2	cal_state [1:0]	Describes the sensor calibration state 0b00: Sensor is not calibrated (default) 0b01: Sensor is calibrated 0b10: Sensor is in warning state 0b11: Sensor calibration is obsolete

Bit	Symbol	Description
1	rev_rot	Indicates if the rotation direction is reversed 0 : Rotation direction is not reversed 1 : Rotation direction is reversed (default)
0	self_cal	Set to 1 if the self-calibration is enabled 0 : Self-calibration is disabled 1 : Self-calibration is enabled (default)

9.4.2 CTRL_REG - Control register (address 20h)

Table 4. STATUS - Status register (address 20h) bit allocation

Bit	7	6	5	4	3	2	1	0
Symbol	reserved			stop_cal	start_cal	ref_zero	rev_rot	self_cal
Reset	—	—	—	0	0	0	0	1
Access	W	W	W	W	W	W	W	W

Table 5. CTRL_REG - Control register (address 20h) field descriptions

Bit	Symbol	Description
4	stop_cal	Controls the calibration stop. 0: no effect (default) 1: stop the current calibration phase (no effect if not InProgress)
3	start_cal	Controls the calibration start 0: No effect (default) 1: Start a new calibration phase (no effect if already InProgress)
2	ref_zero	Sets the current read angle as the zero angle reference 0: No effect (default) 1: Set the angle value to zero
1	rev_rot	Indicates if the rotation direction is reversed 0 : Keep the initial rotation direction (default) 1 : Reverse the rotation direction
0	self_cal	Set to 1 if the self-calibration is enabled 0 : Disable self-calibration 1 : Enable self-calibration (default)

9.4.3 WHO_AM_I - Device identification register (address 0Dh)

Table 6. WHO_AM_I - Device identification register (address 0Dh) bit allocation

Bit	7	6	5	4	3	2	1	0
Symbol	who_am_i [7:0]							
Reset	1	0	1	0	1	0	1	0
Access	R	R	R	R	R	R	R	R

Table 7. WHO_AM_I - Device identification register (address 0Dh) field description

Bit	Symbol	Description
7 to 0	who_am_i	This register contains the NXP unique sensor product identifier and is factory programmed to 0xAA

9.4.4 ANGLE_MSB - Angle output data register (address 01h)

Table 8. ANGLE_MSB - Angle output data register (address 01h) bit allocation

Bit	7	6	5	4	3	2	1	0
Symbol	angle_msb [7:0]							
Reset	0	0	0	0	0	0	0	0
Access	R	R	R	R	R	R	R	R

Table 9. ANGLE_MSB - Angle output data register (address 01h) field description

Bit	Symbol	Description
7 to 0	angle_msb	This register contains the angle sample data. The resolution is 0.00593°/bit, which matches to the full degree scale (0 to 360°) divided by the number of combinations in an unsigned 16-bit register.

9.4.5 ANGLE_LSB - Angle output data register (address 02h)

Table 10. ANGLE_LSB - Angle output data register (address 02h) bit allocation

Bit	7	6	5	4	3	2	1	0
Symbol	angle_lsb [7:0]							
Reset	0	0	0	0	0	0	0	0
Access	R	R	R	R	R	R	R	R

Table 11. ANGLE_LSB - Angle output data register (address 02h) field description

Bit	Symbol	Description
7 to 0	angle_lsb	This register contains the angle sample data. The resolution is 0.00593°/bit, which matches to the full degree scale (0 to 360°) divided by the number of combinations in an unsigned 16-bit register.

9.4.6 SPEED_MSB - Speed output data register (address 03h)

Table 12. SPEED_MSB - Speed output data register (address 03h) bit allocation

Bit	7	6	5	4	3	2	1	0
Symbol	speed_msb [7:0]							
Reset	0	0	0	0	0	0	0	0
Access	R	R	R	R	R	R	R	R

Table 13. SPEED_MSB - Speed output data register (address 03h) field description

Bit	Symbol	Description
7 to 0	speed_msb	This register contains the angular speed sample data expressed as 2's complement numbers. The resolution is 0.8442 rad/s/bit, which matches to the full scale of [-15.000; +15.000 rad/sec] divided by the number of combinations in a signed 16-bit register.

9.4.7 SPEED_LSB - Speed output data register (address 04h)

Table 14. SPEED_LSB - Speed output data register (address 04h) bit allocation

Bit	7	6	5	4	3	2	1	0
Symbol	speed_lsb [7:0]							
Reset	0	0	0	0	0	0	0	0
Access	R	R	R	R	R	R	R	R

Table 15. SPEED_LSB - Speed output data register (address 04h) field description

Bit	Symbol	Description
7 to 0	speed_lsb	This register contains the angular speed sample data expressed as 2's complement numbers. The resolution is 0.8442 rad/s/bit, which matches to the full scale of [-15.000; +15.000 rad/sec] divided by the number of combinations in a signed 16-bit register.

10 Revision history

Revision	Date	Description of changes
1.0	6/2016	Initial release

11 Legal information

11.1 Definitions

Draft — The document is a draft version only. The content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included herein and shall have no liability for the consequences of use of such information.

11.2 Disclaimers

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be

provided in NXP data sheets and/ or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address: nxp.com/salestermsandconditions.

11.3 Trademarks

Notice: All referenced brands, product names, service names and trademarks are the property of their respective owners.

NXP — is a trademark of NXP B.V.

the NXP logo — is a trademark of NXP B.V.

Freescale — is a trademark of NXP B.V.

the Freescale logo — is a trademark of NXP B.V.

Kinetis — is a trademark of NXP B.V.

ARM — is a registered trademark of ARM Limited (or its subsidiaries) in the EU and/or elsewhere.

Cortex — is a registered trademark of ARM Limited (or its subsidiaries) in the EU and/or elsewhere.

Tables

Tab. 1.	Register address map	19	Tab. 9.	ANGLE_MSB - Angle output data register (address 01h) field description	21
Tab. 2.	STATUS - Status register (address 00h) bit allocation	19	Tab. 10.	ANGLE_LSB - Angle output data register (address 02h) bit allocation	21
Tab. 3.	STATUS - Status register (address 00h) field descriptions	19	Tab. 11.	ANGLE_LSB - Angle output data register (address 02h) field description	21
Tab. 4.	STATUS - Status register (address 20h) bit allocation	20	Tab. 12.	SPEED_MSB - Speed output data register (address 03h) bit allocation	21
Tab. 5.	CTRL_REG - Control register (address 20h) field descriptions	20	Tab. 13.	SPEED_MSB - Speed output data register (address 03h) field description	22
Tab. 6.	WHO_AM_I - Device identification register (address 0Dh) bit allocation	20	Tab. 14.	SPEED_LSB - Speed output data register (address 04h) bit allocation	22
Tab. 7.	WHO_AM_I - Device identification register (address 0Dh) field description	21	Tab. 15.	SPEED_LSB - Speed output data register (address 04h) field description	22
Tab. 8.	ANGLE_MSB - Angle output data register (address 01h) bit allocation	21			

Figures

Fig. 1.	RD-KL46Z-MRE evaluation kit	4	Fig. 12.	Angle sensor window	11
Fig. 2.	RD-KL46Z-MRE Block Diagram	5	Fig. 13.	Time view	12
Fig. 3.	RD-KL46Z-MRE Hardware Description	6	Fig. 14.	X/Y view	13
Fig. 4.	Flash the MCU	7	Fig. 15.	Angle error view	14
Fig. 5.	Program upload! window	7	Fig. 16.	Calibration	14
Fig. 6.	Establishing communication	8	Fig. 17.	Equivalent firmware block diagram	15
Fig. 7.	Connected to a computer and communicating	8	Fig. 18.	Customized RD-KL46Z-MRE board with battery and Bluetooth® module	16
Fig. 8.	The board is connected to a computer, but not communicating	9	Fig. 19.	Ratio of output voltage to knob angle	17
Fig. 9.	Port com is connected, but there is no response from the rotary board	9	Fig. 20.	How to connect MCU to the sensor PWM output	17
Fig. 10.	The board is not connected to a computer	9	Fig. 21.	How to connect the sensor to SPI bus	18
Fig. 11.	Calibrating the sensor	10	Fig. 22.	Timing diagram	18

Contents

1	RD-KL46Z-MRE	1
2	Important notice	2
3	Getting started	3
3.1	Kit contents/packing list	3
3.2	Jump start	3
4	Hardware description	3
4.1	Kit overview	3
4.2	Block diagram	5
4.3	Board description	5
4.4	Freedom board configuration	6
5	Setting up the hardware	6
5.1	Prepare the drivers	6
5.2	Install the GUI	7
5.3	Flash the MCU	7
5.4	Establish communication	8
5.5	Calibrate the sensor	9
6	Using the software	10
6.1	Angle sensor window	10
6.2	Magnetics window	11
6.2.1	Time view	12
6.2.2	XY view	13
6.2.3	Angle error view	14
7	Understanding calibration state and self-calibration	14
8	Understanding data output	15
9	Advanced operations	16
9.1	Customizing the RD-KL46Z-MRE	16
9.2	PWM output	16
9.3	SPI bus	17
9.4	Register descriptions	19
9.4.1	STATUS - Status register (address 00h)	19
9.4.2	CTRL_REG - Control register (address 20h) ...	20
9.4.3	WHO_AM_I - Device identification register (address 0Dh)	20
9.4.4	ANGLE_MSB - Angle output data register (address 01h)	21
9.4.5	ANGLE_LSB - Angle output data register (address 02h)	21
9.4.6	SPEED_MSB - Speed output data register (address 03h)	21
9.4.7	SPEED_LSB - Speed output data register (address 04h)	22
10	Revision history	23
11	Legal information	24